



Document: Main Components
 Guide No: 019
 Description: Omega Canopy, Free-Standing, Gable-Roof, Type 1

04 Canopy Main Components

Canopy Component	
RH Eaves Supporting Post/Tie-Bar Bracket/Knee Brace Bracket Assembly	
LH Eaves Supporting Post/Tie-Bar Bracket/Knee Brace Bracket Assembly	
Eaves Intermediate Supporting Post/Tie-Bar Bracket/Knee Brace Bracket Assembly	




Canopy Component	
Ridge Support Post	
Post Foot/Bracket joining Eaves/Gutter and Supporting Post	
Ridge (Wall-Plate Assembly)	

Document: Main Components
 Guide No: 019
 Description: Omega Canopy, Free-Standing, Gable-Roof, Type 1

Page 3 of 6


Canopy Component	
Eaves/ Gutter	
Edge Glazing Bar	
Main Glazing Bar	

Canopy Component	
Sheet Closure (for Roof Panel)	
Roof Panel with protective film on both upper and lower surfaces	
End Cap for Edge Glazing Bar	

Canopy Component	
End Cap for Main Glazing Bar	
End Plate for Eaves/Gutter	
End Plates for Ridge Assembly	

Document: Main Components
Guide No: 019
Description: Omega Canopy, Free-Standing, Gable-Roof, Type 1

Page 6 of 6

Canopy Component	
Tie-Bar	
Rainwater Adaptor	